

Joining Two Patio Deck Kits Together Assembly Instructions



Deck Side Installation

1. Place the next Deck Kit up against the assembled deck as pictured below.



2. Install the spreaders against the first assembled deck kit



3. Once the rim board is installed on the 2nd deck, screw the two rim joints together using the marked black dots to connect the two decks



4. Install connector screws as indicated using 6 screws to join the two decks that come with these instruction.



Deck End Installation

The rim board comes factory installed, to connect the two decks screw the rim boards together as shown below following the black dots that mark the location



Visit us on the Web @
easideck.com

Call us toll free:
877.455.5961

Email us at:
info@easideck.com